

VOR/DME ELN	APP CRS	Rwy Idg	N/A
117.9	260°	TDZE	N/A
Chan 126		Apt Elev	1763

VOR-A

BOWERS FLD (ELN)

NA Procedure NA when R-6714A, F, G, H are in operation. DME required.	MISSED APPROACH: Climbing left turn to 5000 direct ELN VOR/DME and hold.
---	--

ASOS 118.375	SEATTLE CENTER 132.6 269.35	UNICOM 123.0 (CTAF) 1
-----------------	--------------------------------	--------------------------

